

BITMAIN

U3 Server User Guide

Contents

1. The First Glance.....	3
2. Accessories and Connection.....	3
3. Install Driver.....	4
4. Core Voltage & Operating Frequency Adjustments.....	9

1. The First Glance

U3 server is the third generation of USB server. The U3 server utilizes 4 of BITMAIN's latest generation BM 1382 chips in high quality, domed case. Setup consists of plugging in the USB and power cables and running server.



2. Accessories and Connection

2.1 Accessories

The accessories of U3 server including:

12V AC/DC power brick of 6A, but AC power line not included * 1

USB connection cable * 1

2.2 Connection

- a) Plug one side of 12V AC/DC power brick into U3, and plug the other side into AC input.
- b) Connect U3 server and the computer via the USB line.

Noted:

Connection order must be "a)" first, and then "b)". Order cannot be

reversed.

To prevent the interruption of USB power supply, please ensure the computer is not in standby or sleep mode. Otherwise, the cgserver wouldn't find the server even make it ZOMBIE.

3. Install Driver

Click the link below:

<https://www.bitmaintech.com/Support/AntMiner>

20150107.rar Open sourced code for U3 Server, refer to the link below:

<https://github.com/bitmaintech/cgminer>


CP2102 Driver:

[http://www.silabs.com/products/mcu/Pages/](http://www.silabs.com/products/mcu/Pages/USBtoUARTBridgeVCPDrivers.aspx)

[USBtoUARTBridgeVCPDrivers.aspx](http://www.silabs.com/products/mcu/Pages/USBtoUARTBridgeVCPDrivers.aspx)

zadig:


<http://zadig.akeo.ie/>




1> Install CP210x_VCP driver.

2> Plug in U3 Server.

3> Open Zadig and click "Options -> List All Devices"



4> Select CP2102 USB to UART Bridge Controller, and then click “Replace Driver”




XP:


a. Install CP210x_VCP driver.



b. zadig



c.




WIN 7:


a. Install CP210x_VCP driver.



b. zadig



C.




Win 8:


a. Install CP210x_VCP driver



b. zadig



c.



5> Run it following the below

Click it at first, 

```
bmsc-options 115200:0.54 -o 50.31.149.57:3333 -u server -p 123
```

```
--bmsc-voltage 0830 --bmsc-freq 0982 --startdiff 6 some pools:
```

```
p2p.antpool.com:25; solo.antpool.com:3333
```

Noted:

- a) Please note that “115200” stands for the “Baud Rate”, and “0.65” means “timeout”. It changes with Freq you set to guarantee the speed. Details see chart 2.
- b) ‘--startdiff 6’ is to make the low hash rate servers getting a proper difficulty asap, which is still under developing by Antpool
- c) Core Voltage can be changed by setting the figure “0830”
Operating frequency can be changed by setting the figure “0982”

4. Core voltage & Operating Frequency Adjustments

Core voltage and operating frequency can be adjusted by software.

1 > Core Voltage can be changed by setting the figure “0800”.

The voltage varieties from 0.725 to 0.85v, 0.75v by default, and min unit is 0.005v. Higher voltage supports higher Freq. As 0.75v, U3 can work not more than 225M.

Please refer below chart:

Insert Value	Voltage (V)
0725	0.725
0730	0.730
0735	0.735
0740	0.740
0745	0.745
0750	0.750
0755	0.755
0760	0.760
0765	0.765
0770	0.770
0775	0.775
0780	0.780
0785	0.785
0790	0.790
0795	0.795

0800	0.800
0805	0.805
0810	0.810
0815	0.815
0820	0.820
0825	0.825
0830	0.830
0835	0.835
0840	0.840
0845	0.845
0850	0.850

Chart 1

2> Operating frequency can be changed by setting the figure “0882”. Please refer below chart:

Eg. `--bms-coptions 115200:0.57 --bmsc-freq 1286`

Insert Value	Frequency (M)	Prefer timeout (100 ms)
0783	100.00	1.36
0983	125.00	1.09
0B83	150.00	0.91
0D83	175.00	0.78
0F03	193.75	0.71
1F07	196.88	0.69
0782	200.00	0.68
1006	206.25	0.66
1086	212.50	0.64
1106	218.75	0.62
0882	225.00	0.61
1286	237.50	0.57
1306	243.75	0.55

0982	250.00	0.54
------	--------	------

Chart 2

Regulation:

FCC Notice (FOR FCC CERTIFIED MODELS):

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note:

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

EU WEEE: Disposal of Waste Equipment by Users in Private Household in the European Union



This symbol on the product or on its packaging indicates that this product must not be disposed of with your other household waste. Instead, it is your responsibility to dispose of your waste equipment by handing it over to a designated collection point for the recycling of waste electrical and electronic equipment. The separate collection and recycling of your waste equipment at the time of disposal will help to conserve natural resources and ensure that it is recycled in a manner that protects human health and the environment. For more information about where you can drop off your waste equipment for recycling, please contact your local city office, your household waste disposal service or the shop where you purchased the product.

台灣 ROHS:

設備名稱: _____, 型號: _____						
單元	有害物質					
	鉛 (Pb)	汞 (Hg)	鎘 (Cd)	六價鉻 (Cr+6)	多溴聯苯 (PBB)	多溴二苯醚 (PBDE)
外殼	○	○	○	○	○	○
電路板組件	—	○	○	○	○	○
其他線材	—	○	○	○	○	○

備考 1. “超出 0.1 wt %” 及 “超出 0.01 wt %” 係指限用物質之百分比含量超出百分比含量基準值。
備考 2. “○” 係指該項限用物質之百分比含量未超出百分比含量基準值。
備考 3. “—” 係指該項限用物質為排除項目