

INNOSILICON

A4+ LTCMaster USER MANUAL



INNOSILICON A4+ LTCMaster

High Efficient LTCMaster

Table of Contents

1. OVERVIEW	1
2. MINER ASSEMBLE	2
2.1 Check the miner before power on	2
2.2 Connect the PSU	3
2.3 Connect the Ethernet Cable	3
3. ENTER THE MINER CONSOLE	3
4. CONFIG THE MINER	6
5. APPENDIX	10
5.1 Modify the login password	10
5.2 Upgrade the firmware	10

1. OVERVIEW




Part Number	A4+ LTCMaster
Hash Rate	620Mh/s (+-8%)
Power	750W +/-8%
Size (L×W×H)	350mm×125mm×158mm
Net Weight	3.83KG (without PSU)
Operating Temperature	0-40 °C
Required rated PSU	1000W or above, 9 * PCI-E 6Pin
Network Connection	Ethernet

2. CABLE CONNECTION


2.1 CHECK THE MINER BEFORE POWER ON

- Check the warranty sticker is well or not, especially the hashboards PSU port side. If the warranty sticker is damaged when you received the miner, please contact our After-sales.
- Before you power on the miner, shake the miner softly, if you can hear the sound of metal banging on metal, please contact our After-sales.
- Check if the fan work well, if you find the fans broken please contact our After-sales.
- Check the cable connection, if it is different from below picture, please connect the cables as below.




2.2 CONNECT THE PSU

Every hash board needs to be inserted with 2 PSU cables, controller only needs 1 PSU cable according to the following image .



2.3 CONNECT THE ETHERNET CABLE

Insert one end of the Ethernet cable into the router and the other end into the slot shown in the following image, you should plug in the miner one by one, only when you have accomplished IP Setting of the previous one you can plug in another miner .




IP SET button: Press it more than 5 seconds to recover the IP to 192.168.1.254.

RESET button: Your miner will restart if you press it. It wont recover your settings to the default.

3. ENTER THE MINER CONSOLE

By default, the miner uses Static IP to access the control webpage of the miner.

Input 192.168.1.254 into the browser, then click 'Enter' to enter the miner's control webpage (Chrome is the suggested browser).




Cant access the miner console?


Maybe it is because miner IP and the router IP have a different network segment, two ways to solve it:

- Modify the router IP to 192.168.1.1, then try again.
- Don't want to change the network segment of the router? Do it as below:

Connect the miner and computer with a network cable. Open the windows system control panel, go to Network and Internet — Network and share center – change the adapter settings, the mouse cursor to the “Local Area Connection” click the right mouse button to view properties.



- Press the OK button twice to confirm the changes. Then modify the IP address of the miner (Do it as the follow step g) to guarantee the miner and the router have the same network segment. Then connect the miner with the router, connect the PC with the router and select the "Obtain the IP address automatically". Now you can enter the IP through the browser into the control interface



- Press the OK button twice to confirm the changes. Then modify the IP address of the miner (Do it as the follow 4.4) to guarantee the miner and the router have the same network segment. Then connect the miner with the router, connect the PC with the router and select the “Obtain the IP address automatically”. Now you can enter the IP through the browser into the control interface

4. CONFIG THE MINER

4.1 Enter ‘Miner Configuration’ page, select ‘General Settings’. Click the lower right corner enter log in page.



Miner Configuration | System | Network

General Settings

Miner General Configuration

Pool1
URL: stratum+tcp://dash.s.innomining.com:2000
Worker: inno.102
Password: x

Pool2
URL:
Worker:
Password:

Pool3
URL:
Worker:
Password:

Pool4
URL:
Worker:
Password:

Frequency
Miner Running Frequency(MHz): 1100
(Note: 1100MHz is our default frequency with voltage VID range of 20 to 16. The lower VID value means the higher voltage or higher power consumption. If you want to try overclock frequency, you usually need to adjust VID to be lower. Warning: overclock is at your own risk and vary in performance from miner to miner. It may damage miner in overheating condition.)

Voltage
Miner Operational Voltage(Level): 12
(Note: VID 16 is our default voltage setting and the most suitable value of VID may vary from miner to miner. User can slightly adjust VID up or down to get the best performance. 1100MHz is our default frequency with voltage VID range of 20 to 16. The lower VID value lower means the higher voltage. If you want to try higher overclock frequency, you may need to adjust VID to be lower. Warning: overclock is at your own risk and vary in performance. It may damage miner in overheating condition.)

Config

4.2 Enter the default password “12345678”, then click lower right corner configuration page.



to enter

Password is wrong/error?—Please contact our after-sales people.


4.3 Enter the mining pool’s URL, Worker, password according to the following image, then click . The miner will start mining, and the page will return to the ‘Miner Configuration’ page. It will show the user’s modified setting.

4.4 To avoid IP conflict when using 2 or more miners at the same time, the IP address needs to be changed. Enter the network interface shown in the following image, and modify the IP address to you need, then click the “Save” to save it.

Note : If you change the miner IP address to another network segment, after you save it there will be 3 circles keep spinning,that is ok.

- > IP address: If the router address is 192.168.0.1 , you can change the miner’s IP address to 192.168.0.# (# can be any number between 10-253 but every miner’s # must be unique) .
- > Subnet mask: Keep it consistent with your computer.
- > Gateway: Same with the router address.
- > DNS: It is recommended to modify the DNS to the local network operator near the location of the miner. For example, the mining machine uses telecommunication broadband in Beijing, China. Search in Baidu or Google search engine "Beijing Telecom DNS" to get the DNS: 219.141.136.10. Then use this DNS for your miner.

When the above information is input, click the lower right corner  to save.



4.5 Enter ‘Miner Status’ page to check the status on the mining pool configuration and performance of the miner.

INNOSILICON

Miner Status
Miner Configuration
System
Network

Miner Status

Summary Auto Refresh : 0S

Running Time	Accepted / Rejected	HW	Fan Speed	Total HashRate(MHS)
04h 48m 51s	10184 / 5	16	100%	681.13

InnoMiner

Chain#	Accepted / Rejected	HW	Temp min / Temp max / Temp avg	Status	HashRate(MHS)
ASC0	2628 / 1	4	37.14 / 65.62 / 51.98	Alive	171.27
ASC1	2482 / 1	4	40 / 65.62 / 51.88	Alive	170.47
ASC2	2550 / 0	4	37.14 / 68.75 / 50	Alive	169.69
ASC3	2524 / 3	4	38.57 / 66.25 / 51.98	Alive	169.70


HW: means error in calculating

INNOSILICON CONFIDENTIAL


5. APPENDIX

5.1 MODIFY THE LOGIN PASSWORD

Select the "Administration" interface at System, then you can modify your password. Then click  to save your new password.



5.2 UPGRADE THE FIRMWARE



Build date is the version of the firmware. If your miner build date is before NOV 24, please upgrade your miner via a TF card. Here is the instruction:

<http://www.innosilicon.com.cn/api/download.php?url=TF-card-firmware-update-manual-en.pdf>

If your miner build date is NOV 24 or later, a web upgrade is OK, you can do it as below .

Select the “Upgrade” interface at System option, click to choose the firmware you want to upgrade, click the “update” to start the upgrade. The upgrade is success when you see the progress bar reach to 100%.

INNOSILICON

Miner Status | Miner Configuration | **System** | Network

Overview | Administration | **Upgrade**

Upgrade

Note: Don't power off the miner when is is upgrading. When the progress bar reach to 100%, upgrade done and it will reboot by itself. Then use "Ctrl+F5" to refresh.

Flash new firmware image

Upload a sysupgrade-compatible image here to replace the running firmware.
Please don't power off during upgrade, Use ctrl+F5 refresh.

Image: