

INNOSILICON

**T2TZ-30T BTC
USER MANUAL**



1.Overview	0
2.1 Open the package to check the miner.....	1
3.Operate the miner.....	4
3.1 Enter the miner console.....	4
3.2 Configure the pool	5
3.3 View the miner hash rate.....	6
3.4 Network configuration.....	6
3.5.1 Change the operation mode	7
3.5.2 Overview	7
3.5.3 Firmware upgrade.....	8
3.5.4 Modify the login password	8
3.5.5 Reboot.....	8
3.5.6 Factory reset	9

1. Overview



Specifications

Part Number	T2TZ-30T
Algorithm	Sha256
Size (L×W×H)	422mm(L)*142mm(W)*213mm (H)
Net Weight	9.5KG
Operating Temperature	0--40 °C(device junction temperature)
Network Connection	Ethernet

Typical Hash rate and Power Dissipation parameters under the four Modes: (Pls refer to 3.5.1 in the manual for mode modification)

Mode	Performance	Factory	Balance	Efficient
Hash rate	30TH±5%	29TH±5%	26TH±5%	24TH±5%
Power dissipation	2200W±10%	2100W±10%	1900W±10%	1620W±10%

2. Assemble the miner

2.1 Open the package to check the miner

- Check whether the warranty sticker is damaged, especially the one on hash boards PSU port side. If the warranty sticker is damaged when you receive the miner, please contact our after-sales personnel in time.
- Before assembling the miner, pls shake the miner gently. Please contact our after-sales personnel immediately if there is metallic collision sound.
- Check whether the two fans work well, if you find the fans broken please contact our after-sales personnel.
- The wiring of the miner shall not be changed.



Notes:

There is an indicator on each hash board which shows the work status of the hash board.

Being constantly lit means the hash board works properly.


Flickering represents overtemperature of the hash board. Please check the fans of the miner, environment temperature and the ventilation conditions.

Being off means the hash board doesn't work. Please try to reboot the miner or change the data cable. Pls contact our after-sales team if the problem still exists.

2.2 Assemble & Operate

Connect the miner and the router by the Ethernet cable and then the miner can start to run after being powered on.

Notes: T2TZ-30T miners consume much more power under some modes. Pls choose proper sockets.



Normal Indicator: Being constantly lit represents static IP and flickering represents DHCP

Fault Indicator: Being on means there is something wrong with the network; Being off means it is OK.

IP SET button:

Press it for 1 to 4 seconds and the following functions can be realized:

- (1) Sending the IP miner to the “Set IP” tool;
- (2) Changing the miner to a Static IP within the specific range with the IPset tool

Press it for 4 to 15 seconds, the miner IP will be switched to DHCP and the pool settings will be restored to default settings.

Press it for 15 to 30 seconds to switch the Dynamic (Static) IP to Static (Dynamic).


RESET button: Press the “Reset” button to restart the miner.

3. Operate the miner


3.1 Enter the miner console

DHCP is the default IP mode of the miner (The normal indicator of the control board now is flickering in green when the DHCP service of the router is enabled.). Find the IP via the IP scanner or the SetIP tool developed by our company. Pls refer to the official support center for the downloading address https://www.innosilicon.com/html/support_en/tool.html.


a. Save SetIP in the pc on the same network with the miner, then double click the tool and choose the language.



b. Report the miner IP



Enter the IP of the miner in the browser and press the Enter button to go to the miner console page. Chrome is the suggested browser. (Please try with dragonadmin if the password admin is invalid.)



3.2 Configure the pool

Please configure the pool to start mining after login.


Please use the suggested pool as below:

- 1 f2pool: stratum+tcp://btc-65536.f2pool.com:3333
- 2 poolin: stratum+tcp://btc-bj.ss.poolin.com:1800 or stratum+tcp://btc-sz.ss.poolin.com:1800
- 3 ckpool: stratum+tcp://cn.ckpool.org:443 or stratum+tcp://pool.ckpool.org:3333
- 4 btc.top: stratum+tcp://t2.btc.top:8888 or stratum+tcp://bak.t2.btc.top:3333
- 5 slushpool: stratum+tcp://stratum.slushpool.com:3333

The screenshot shows the Innosilicon miner console interface. On the left, there's a sidebar with links like Miner Status, Settings (which is active and highlighted in blue), Pools (also highlighted in blue), Security, Network, and Performance. Below that is a dropdown for Maintenance, Overview, and Logout. The main content area is titled "Settings" and "Mining Pools". It shows three pools: Pool 1, Pool 2, and Pool 3. Each pool has fields for URL, Worker, and Password. A red box highlights the URL field for Pool 1, which currently contains "stratum+tcp://btc-bj.ss.poolin.com:1800". A red arrow points from the text "Pls add 'stratum+tcp'" before the pool URL" to this field. The URL fields for Pool 2 and Pool 3 also contain "stratum+tcp://stratum.slushpool.com:3333". The Worker and Password fields for all three pools are also visible.

3.3 View the miner hash rate

After configuring the pool, the miner will mine for you. You can view the hash rate in the Miner Status screen.



3.4 Network configuration

The screenshot shows the 'Network' settings page with the following configuration:

- Network Settings**:
 - DHCP**: A checkbox labeled "Please check this box if you want the miner to receive an IP address automatically from your DHCP server." (unchecked).
 - IP**: 20.20.20.105
 - Netmask**: 255.255.255.0
 - Gateway**: 20.20.20.1
 - DNS 1**: 208.67.222.222
 - DNS 2**: Name Server 2
- Update** button (highlighted with a red box and arrow).

3.5 Other pages

3.5.1 Change the operation mode


There are 4 modes available and please click the “Save” icon after your modification.

The screenshot shows the INNOSILICON Miner Profile interface. On the left, a sidebar menu includes: Miner Status, Settings, Pools, Security, Network, **Performance** (which is highlighted with a red box), Maintenance, Firmware, Reboot, Factory Reset, Miner Logs, Overview, and Logout. The main content area is titled "Miner Profile" and "Performance". It displays a "Profiles" section with a note about four tuning modes: Efficiency, Balanced, Factory, and Performance. A progress bar at the bottom indicates the tuning process from Efficiency to Performance. Below this is a "Tuning Status" section showing Current Mode as "factory" and Tuning Status as "tuned". A blue "Save" button is located at the bottom left of this section.


3.5.2 Overview

The screenshot shows the INNOSILICON Overview page. On the left, a sidebar menu includes: Miner Status, Settings, Maintenance, **Overview** (which is highlighted with a red box), and Logout. The main content area is divided into three sections: "Version", "Network Status", and "System".
Version:
Type: B29
Controller Version: g19
MAC Address: a0:b0:45:00:2f:94
Build Date: **firmware version** 17th of April 2018 12:42 PM
Platform Version: b29_20180417_124258
Network Status:
Type: dhcp
IP: 20.20.20.105
Netmask: 255.255.255.0
Gateway: 20.20.20.1
Name Server 1: 208.67.222.222
Name Server 2:
System:
Uptime: 08:08:10 up 57 min, load average: 0.73, 0.73, 0.67
Memory Used: 55336 kb / 250544 kb (22%)
Memory Free: 195208 kb / 250544 kb (78%)
Cached Used: 33676 kb / 244628 kb (14%)
Cached Free: 210952 kb / 244628 kb (86%)


3.5.3 Firmware upgrade



3.5.4 Modify the login password



3.5.5 Reboot



3.5.6 Factory reset

